

### Driven Monza Mirror

Part# DMBEM

### INSTALLATION INSTRUCTIONS

**THIS MIRROR IS NOT SIDE SPECIFIC, IT WILL WORK FOR LEFT OR RIGHT**

**FOR BIKE SPECIFIC ADAPTERS, GO TO [WWW.DRIVENRACING.COM/CATALOG/BAR-END-ADAPTER](http://WWW.DRIVENRACING.COM/CATALOG/BAR-END-ADAPTER)**

#### NOTES:

- The star nut adapter to be used with bars that are .500-.625 id. (Fig.1)
- The wedge type adapter can be used on bars that are .625-.725 id. (Fig. 2)
- Decide on the right side adapter and install the mirror using that size.

#### WARNING:

**You must use blue loctite on M5 x 25 screw. Failure to do so may cause the mirror to loosen and fall!**

These adapters are designed to fit hollow bars only

Figure 1



Figure 2

