

FOR OFF ROAD/RACE USE ONLY!



**DRIVEN ALUMINUM COLLAR GRIPS
INSTALLATION INSTRUCTIONS**

**DRIVEN PERFORMANCE PRODUCTS
WWW.DRIVENRACING.COM
866-5-DRIVEN**

Driven grips installation instructions:

For the below models:

- D-3 GRIPS
 - D-AXIS GRIPS
 - HALO GRIPS
-
- Remove OEM grips. (You can cut them off if they are glued on)
 - Make sure both sides throttle and clutch are smooth and clean.
 - (If there are ridges on the throttle tube you will need to smooth them out prior to installation)
 - Look at your new grips there are 2 different grips per package, you will see a larger diameter and a smaller diameter grips, the larger diameter will fit on the right side or the throttle side, the smaller diameter is for the left side or clutch side.
 - Driven recommends the use of grip glue (part number DGG-1)
 - Apply a small amount of WD-40 under the metal part of the grip between the collar and the grip.
 - Apply glue on the inside of the grip on the front portion of the grip.
 - Push the grip in a circular motion forward grabbing the collar and the grip, the glue will lubricate the grip and help guide it on. Make sure it's done fast as the glue is setting quickly.
 - Repeat on the other side.

Notes:

If you don't wish to use glue make sure you use a lubricant like WD-40 or similar.

Don't use brake cleaner or harsh chemicals.

Don't pull on the grip without the collar as it will rip.

THIS PRODUCT IS INTENDED TO BE INSTALLED BY A CERTIFIED TECHNICIAN*