



OFF ROAD/CLOSED COURSE USE ONLY

PART#: DFCB-BM/DFC (DRIVEN FUEL CAP/BASE FOR BMW S1000RR)
(Installation Instructions)

1. Make sure you have all of the required parts for installation. (see checklist)
2. Remove stock (OEM) fuel cap completely along with the gasket. Locate vent hole. (see image)
3. Install OEM gasket onto the underside of the lower base.
4. Install vent hose through lower base and into tank and install lower base with part# facing upwards using the shorter screws. It is highly recommended to use blue Loctite. (see image)
5. Make sure not to crush/kink the vent hose and install the fuel cap base. It is highly recommended to use blue Loctite.
6. Install the ¼ turn cap by pushing down and turning clockwise until it locks into place. You can release the cap by pushing down and turning it counter-clockwise.
7. Double check all mounting hardware after 500 miles of use.

TOOLS REQUIRED

- 4mm hex key
- blue (#242) Loctite

PARTS CHECKLIST*

- Fuel cap
- O-Ring (installed on fuel cap)
- D-AXIS fuel cap base
- Gasket (installed on fuel cap base)
- Fuel cap lower base
- Vent hose (installed on lower base)
- Hardware (3 short screws/4 long screws)

DRIVEN PERFORMANCE PRODUCTS
WWW.DRIVENRACING.COM
866-5-DRIVEN

TORQUE SPECS AND INFO

- All Hardware: 6FT/LBS

THIS PRODUCT TO BE INSTALLED ONLY BY A CERTIFIED TECHNICIAN



OFF ROAD/CLOSED COURSE USE ONLY

PART#: DFCB-BM/DFC (DRIVEN FUEL CAP/BASE FOR BMW S1000RR)
(Installation Instructions)

1. Make sure you have all of the required parts for installation. (see checklist)
2. Remove stock (OEM) fuel cap completely along with the gasket. Locate vent hole. (see image)
3. Install OEM gasket onto the underside of the lower base.
4. Install vent hose through lower base and into tank and install lower base with part# facing upwards using the shorter screws. It is highly recommended to use blue Loctite. (see image)
5. Make sure not to crush/kink the vent hose and install the fuel cap base. It is highly recommended to use blue Loctite.
6. Install the ¼ turn cap by pushing down and turning clockwise until it locks into place. You can release the cap by pushing down and turning it counter-clockwise.
7. Double check all mounting hardware after 500 miles of use.

TOOLS REQUIRED

- 4mm hex key
- blue (#242) Loctite

PARTS CHECKLIST*

- Fuel cap
- O-Ring (installed on fuel cap)
- D-AXIS fuel cap base
- Gasket (installed on fuel cap base)
- Fuel cap lower base
- Vent hose (installed on lower base)
- Hardware (3 short screws/4 long screws)

DRIVEN PERFORMANCE PRODUCTS
WWW.DRIVENRACING.COM
866-5-DRIVEN

TORQUE SPECS AND INFO

- All Hardware: 6FT/LBS

THIS PRODUCT TO BE INSTALLED ONLY BY A CERTIFIED TECHNICIAN

Vent hole



Lower installed



Fuel cap installed



OEM gasket



Lower base



Vent hole



Lower installed



Fuel cap installed



OEM gasket



Lower base

