

FOR OFF ROAD/RACE USE ONLY!



**PART#: DTDLG-X-XX (TRACK DAY LEVER GUARD)
INSTALLATION INSTRUCTIONS**



For Most Aftermarket/OEM Hollow Bars

1. Determine the inside diameter of the handlebars you are using.
14mm-17mm bars --> Star fangled nut
16.5mm-19mm bars --> Aluminum expansion sleeve
2. For use with the star fangled nut (SFN): Using the longer 6mm hardware, screw the bolt into the SFN and gently tap the SFN into the bar with the tips facing away from the bike just until it sits below flush in the bar. Remove the screw and assemble the lever using the 6mm anodized bushing and the 6mm x 35mm screw. Mount the guard into the desired position and turn the handlebars from left to right to make sure the guard does not make contact with any other parts of the bike. Tighten until snug.
3. For installation with expanding bushing, insert bushing halfway into the bar. Make sure to tighten the nut, so bushing goes in tight. Once in, push it the rest of the way in, and tighten the bolt until tight.
4. Mount the guard into the desired position and turn the handlebars from left to right to make sure the guard does not make contact with any other parts of the bike. Gently tighten until snug.
5. Check all hardware once more after a couple rides to ensure everything remains snug.

THIS PRODUCT IS INTENDED TO BE INSTALLED BY A CERTIFIED TECHNICIAN*