

**FOR OFF ROAD/RACE USE ONLY!**



**Part#:DBEW-XX**

**INSTALLATION INSTRUCTIONS**

The Driven Racing line of bar ends that are included in this installation instruction are as followed:

- Driven Bar Ends v-1
- Driven Bar Ends v-2
- Driven D-Axis Bar Ends
- Driven SS Bar Ends

All driven bar ends are universal fit and are not bike specific.

- Make sure your bike has hollow bars or a 6mm threaded end.
- If your bars are hollow make sure the i.d.(inside diameter) is 15.5 mm to 18.5 mm.
- Apply blue Loctite on the nut.
- Insert the expendable sleeve into the bar until flush with the end of the bar and with a rag turn the bar end clockwise until tight give it an extra ¼ turn and let the blue Loctite dry for about an hour.
- Repeat same for the other side.

\* If your bar i.d. is 13.5-14.5 please order part number dbew-adp.

\*if your bars have a 6mm threaded hole remove the nut, expendable sleeve and washers apply blue Loctite on the threads and screw into the bar until flush and tight with the end of the bar, turn another ¼ turn with a rag . Repeat on the other side.

**THIS PRODUCT IS INTENDED TO BE INSTALLED BY A CERTIFIED TECHNICIAN\***

**FOR OFF ROAD/RACE USE ONLY!**



**Part#:DBEW-XX**

**INSTALLATION INSTRUCTIONS**

The Driven Racing line of bar ends that are included in this installation instruction are as followed:

- Driven Bar Ends v-1
- Driven Bar Ends v-2
- Driven D-Axis Bar Ends
- Driven SS Bar Ends

All driven bar ends are universal fit and are not bike specific.

- Make sure your bike has hollow bars or a 6mm threaded end.
- If your bars are hollow make sure the i.d.(inside diameter) is 15.5 mm to 18.5 mm.
- Apply blue Loctite on the nut.
- Insert the expendable sleeve into the bar until flush with the end of the bar and with a rag turn the bar end clockwise until tight give it an extra ¼ turn and let the blue Loctite dry for about an hour.
- Repeat same for the other side.

\* If your bar i.d. is 13.5-14.5 please order part number dbew-adp.

\*if your bars have a 6mm threaded hole remove the nut, expendable sleeve and washers apply blue Loctite on the threads and screw into the bar until flush and tight with the end of the bar, turn another ¼ turn with a rag . Repeat on the other side.

**THIS PRODUCT IS INTENDED TO BE INSTALLED BY A CERTIFIED TECHNICIAN\***