# FOR OFF ROAD/RACE USE ONLY!



Driven TT Rearsets for Yamaha R-6 06-16 Part#: DRP-704 INSTALLATION INSTRUCTIONS

#### Removal

- 1. Remove left side (shifter side) frame bracket.
- 2. Remove shift lever.
- 3. On the right side (brake side) remove exhaust hanger bolt.
- 4. Remove right side frame bracket .
- 5. Remove master cylinder plunger pin (save the cotter pin).
- 6. Remove master cylinder from frame bracket.

### **TOOLS REQUIRED**

- 8mm Open End Wrench
- 5mm Hex Kev
- 6mm Hex Key
- 8mm Hex Key
- · Needle Nose Pliers
- Screw Driver
- Blue Loctite
- Impact Gun

# THE USE OF BLUE LOCTITE IS REQUIRED ON ALL MOUNTING HARDWARE!

#### Installation

NOTE: ALL PIVOT POINTS MUST BE TIGHTENED USING BLUE LOCTITE AND AN IMPACT GUN.

To retain the use of the rear brake light switch a separate M10 X 1.25 aftermarket brake light switch (not included) will need to be used.

### **Brake Side**

- 1. Install master cylinder into left frame bracket.
- 2. Install master cylinder plunger pin and reuse cotter pin.
- 3. Install frame bracket to bike.
- 4. Tighten all bolts (using blue Loctite).

#### **Shifter Side**

- 1. Install left side foot peg into frame bracket.
- 2. Install frame bracket assembly onto bike.
- 3. Install shift pedal and thread shift rod into both hiem joints (left and right).
- 4. Adjust pedal height to desired position by rotating shift rod.
- 5. Tighten all bolts and nuts (use blue Loctite).


Note. If "gp shift pattern" is desired rotate shift knuckle 180 degrees.

## **TORQUE VALUES**

- M5 = 6FT/LBS
- M6 = 10FT/LBS
- M8 = 25FT/LBS
- M10 = 45FT/LBS

Make final adjustments as necessary and re-check all hardware after the first 500 miles of use.





Brake Side Shifter Side

# FOR OFF ROAD/RACE USE ONLY!



