FOR OFF ROAD/RACE USE ONLY!

Driven TT Rearsets for 2016 Kawasaki ZX-10R Part#: DRP-723 INSTALLATION INSTRUCTIONS

Removal

Shifter Side

- 1. Remove OEM shift rod from bike.
- 2. Remove frame plate from bike.

Brake Side

- 1. Remove 2 m8 bolts holding heal guard.
- 2. Remove master cylinder plunger pin and retain split pin.
- 3. Remove 2 m8 bolts and remove frame bracket.
- 4. Remove rear brake switch and disconnect it from bike.

TOOLS REQUIRED

- 8mm Open End Wrench
- 5mm Hex Key
- 6mm Hex Key
- 8mm Hex Key
- Needle Nose Pliers
- Screw Driver
- Blue Loctite
- Impact Gun

THE USE OF BLUE LOCTITE IS REQUIRED ON ALL MOUNTING HARDWARE!

Installation

NOTE: ALL PIVOT POINTS MUST BE TIGHTENED USING BLUE LOCTITE AND AN IMPACT GUN.

To retain the use of the rear brake light switch a separate M10 X 1.25 aftermarket brake light switch (not included) will need to be used.

Shifter Side

- 1. Install foot peg in frame bracket.
- 2. Install shift rod.
- 3. Install frame bracket onto bike.
- 4. Adjust shift pedal with shift rod and tighten both safety nuts.

*For gp shift an ECU re flash will be required(if used with Kawasaki stock QS) Brake Side

- 1. Install foot peg in frame bracket.
- 2. Connect master cylinder plunger to brake lever using OEM cotter and pin.
- 3. Install frame bracket to bike.
- 4. Install master cylinder using 2 m8 bolts supplied.
- 5. Use blue Loctite on all bolts and torque all to required setting.
- 6. Make sure nothing interferes with proper operation of motorcycle.

Make final adjustments as necessary and re-check all hardware after the first 500 miles of use.






THIS PRODUCT IS INTENDED TO BE INSTALLED BY A CERTIFIED TECHNICIAN*


- TORQUE VALUES
 - M5 = 6FT/LBS
- M6 = 10FT/LBS
- M8 = 25FT/LBS
 M10 = 45FT/LBS
- IVITU = 45FT/LBS












STANDARD SHIFT

REVERSE SHIFT

THIS PRODUCT IS INTENDED TO BE INSTALLED BY A CERTIFIED TECHNICIAN*



THIS PRODUCT IS INTENDED TO BE INSTALLED BY A CERTIFIED TECHNICIAN*