FOR OFF ROAD/RACE USE ONLY!



Driven TT Rearsets for 2017 Suzuki GSXR 1000/R Part#: DRP-731 INSTALLATION INSTRUCTIONS

Removal

Shifter Side

- 1. Remove shift rod from shifter.
- 2. Remove shift pedal from bike.
- 3. Remove 2 M8 bolts from frame bracket and remove plate from bike.

Brake Side

- 1. Remove 2 M6 bolts holding the master cylinder.
- 2. Remove master cylinder plunger pin and retain split pin.
- 3. Remove 2 M8 bolts and remove frame bracket.
- 4. Remove rear brake switch, you will be reusing it.

TOOLS REQUIRED

- 8mm Open End Wrench
- 5mm Hex Key
- 6mm Hex Key
- 8mm Hex Key
- Needle Nose Pliers
- Screw Driver
- Blue Loctite
- Impact Gun

THE USE OF BLUE LOCTITE IS REQUIRED ON ALL MOUNTING HARDWARE!

Installation

NOTE: ALL PIVOT POINTS MUST BE TIGHTENED USING BLUE LOCTITE AND AN IMPACT GUN.

Shifter Side

- 1. Install new shift pedal.
- 2. Connect shift rod.
- 3. Install foot peg into left bracket.
- 4. Install frame bracket using M8 bolts.
- 5. Adjust shift pedal with shift rod for reverse shift simply rotate shift knuckle.

Brake Side

- 1. Install foot peg in frame bracket.
- 2. Connect master cylinder plunger to brake lever using oem cotter pin and pin.
- 3. Install frame bracket to bike.
- 4. Install master cylinder using 2 M6 bolts supplied.
- 5. Use blue Loctite on all bolts and torque all to required setting.
- 6. Make sure nothing interferes with proper operation of motorcycle.

TORQUE VALUES

- M5 = 6FT/LBS
- M6 = 10FT/LBS
- M8 = 25FT/LBS
- M10 = 45FT/LBS

To connect the brake light switch to rear sets, use OEM switch and Driven supplied bracket. See Fig 3.

You will need to bend the spring and adjust the switch light to achieve proper brake light activation

Make final adjustments as necessary and re-check all hardware after the first 500 miles of use.

FOR OFF ROAD/RACE USE ONLY!








(Fig 1.) (Fig 2.)



(Fig 3.)



Brake Side Assembly



Shift Side Assembly

