

Driven Racing Dual Temperature Tire Warmers

Warning:

- Do not leave tire warmer unattended.
- Do not use tire warmer in water or wet conditions.
- Do not ride or use tire warmer when the motorcycle weight is on the warmer .As this will damage the warmers and void the warranty.
- Do not use these tire warmers on smaller tires as overlap will damage the warmer.
- Use on tires 120 front and 190/200 rear only.
- If you notice a sign of visible damage do not use the warmers and contact Driven Racing.

How to use:

- Remove tire warmers from carrying bag.
- Install tire warmers on wheel using the strap and start at one of the spokes, rotate the tire by hand and apply the warmer evenly against the tire surface. Once you reach the end closed it on the Velcro portion of the warmer.
- Connect the power cord to electricity source and turn the switch to **low** For about 30 to 40 minutes about 10-15 Minutes prior to you ride time turn switch to **high** The tire will reach the optimal temperature . (based on outside temperature you may need to adjust the time period the warmers are on)
- When you are ready to ride unplug the power supply cord remove the warmers and set them aside in a safe place.

